

# ADA Lift (PL-72/PL-50)

## OPERATING INSTRUCTIONS

1. At ground level move wheelchair or scooter onto the lift platform.
2. If you are in a wheelchair, lock the brakes on the chair.
3. To operate the lift push and hold the "UP" on the control pad. The lift will automatically shut off if the user takes their hand off the control pad.
4. Once the platform makes a complete stop at stage level the passenger may exit the lift. The lift will automatically shut off once the platform has reached the stage.
5. At upper landing (stage) move wheelchair or scooter onto the lift platform.
6. If you are in a wheelchair, lock the brakes on the chair.
7. Turn the key to the "ON" position.
8. To operate the lift push and hold the "DOWN" on the control pad.
9. Once the platform reaches the ground it will shut off and the ramp will unfold.
10. It is now safe to exit the lift platform.

## EMERGENCY HAND CRANK OPERATION

1. Insert hand crank into access hole and turn slowly until it catches the gear box shaft and tooth.
2. Turn hand crank "COUNTER CLOCKWISE" to raise lift platform "UP"
3. Turn hand crank "CLOCKWISE" to lower lift platform "DOWN."

